



# ИНСТРУКЦИЯ ПО СБОРКЕ

## БРИСБЕН тумба для ТВ



(GB) Assembly instructions

(IT) Istruzioni di montaggio

(PL) Instrukcja montażu

(SK) Návod na montáž

(RO) Instrucțiuni de montaj

(TR) Montaj talimatları




(D) Montageanleitung

(FR) Notice de montage




(NL) Handleiding voor de montage




(CZ) Montážní návod

(HU) Szerelési útmutató



30 min








№	Size/MaB	Qty	✓
1	1400x460x330	1	
2	1400x460x250	1	

<b>J4</b> x10  4x35	<b>J5</b> x8  4x40	<b>R1</b> x4 	
<b>X7</b> x2 	<b>H1</b> x2  M4x22(25)	<b>X7</b> x1 	<b>H2</b> x1  M4x40
для дверей		для ящика	

1

J4 x10	J5 x8	R1 x4
		
4x35	4x40	

