





ИНСТРУКЦИЯ ПО СБОРКЕ

АДЕЛАИДА книжный шкаф 1



R




L









- D** Montageanleitung
- FR** Notice de montage
- NL** Handleiding voor de montage
- CZ** Montážní návod
- HU** Szerelési útmutató
- TR** Montaj talimatları





- GB** Assembly instructions
- IT** Istruzioni di montaggio
- PL** Instrukcja montaży
- SK** Návod na montáž
- RO** Instrucțiuni de montaj
- ES** Instrucciones de montaje



50 min


















G1x1  Ø6x60	V1x1  Ø3.5x62	P1x1 	J2x8  4x16	Gx14 	Z7x4 
					J11x4  3.5x13




NR	HxBxT (mm)	Qty.	
1	648x1900x487	1	
2	602x334x6	3	
3	1416x526x4	1	
4	1509x522x20	1	

1



3

G x2



4

Z7 x4




J11 x4








3.5x13

G x12



5 x2






4 x2

4

D x4




4x25

A top



B bottom





C 4x25





5 x2



+2 / -2 mm




+2 / -0,5 mm




+1,5 / -1,5 mm





- D *Push-To-Open einstellen*
- GB *Adjusting the Push-To-Open*
- FR *Régler les Push-To-Open*
- IT *Sistemare Push-To-Open*
- NL *Push-To-Open instellen*
- PL *Nastawić montażu*
- CZ *Vyrovnejte Push-To-Open*
- RO *Nastavenie Push-to-Open*
- HU *Állítsa be az Push-To-Open*
- SK *Reglare Push-To-Open*
- TR *Push-To-Open ayarlanması*

1



2

