




ИНСТРУКЦИЯ ПО СБОРКЕ

АДЕЛАИДА книжный шкаф 2








- ES** Instrucciones de montaje
- FR** Notice de montage
- NL** Handleiding voor de montage
- CZ** Montážní návod
- HU** Szerelési útmutató
- TR** Montaj talimatları



- GB** Assembly instructions
- IT** Istruzioni di montaggio
- PL** Instrukcja montażu
- SK** Návod na montáž
- RO** Instrucțiuni de montaj
- D** Montageanleitung





50 min













G1 x2	V1 x2	P1 x2	J2 x4	G x14
				
Ø6x60	Ø3.5x62		4x16	



NR	HxBxT (mm)	Qty.	
1	1013x1400x487	1	
2	969x326x6	2	
3	915x484x4	2	
4	1009x442x20	2	









1






2


G x14




3 x2




C 4x16






4 x2



D x4




4x25

A top



B bottom





C 4x25





5 x2



+2 / -2 mm




+2 / -0,5mm




+1,5 / -1,5mm





- D *Push-To-Open einstellen*
- GB *Adjusting the Push-To-Open*
- FR *Régler les Push-To-Open*
- IT *Sistemare Push-To-Open*
- NL *Push-To-Open instellen*
- PL *Nastawić montażu*
- CZ *Vyrovnejte Push-To-Open*
- RO *Nastavenie Push-to-Open*
- HU *Állítsa be az Push-To-Open*
- SK *Reglare Push-To-Open*
- TR *Push-To-Open ayarlanması*

1



2

